



Congratulations! You have joined the growing number of households to enjoy the many benefits of owning a DAS Ducted Vacuum System.

Your DAS Ducted Vacuum System is a lifestyle improvement for you and your family. Follow these simple maintenance and care instructions for trouble free vacuuming for many years to come.

OPERATING YOUR DUCTED VACUUM SYSTEM

Inside the Home


1. Plug in the cuff end of the hose into the nearest wall inlet inside your home and the power unit will automatically turn on, ready for you to begin vacuuming.
2. The power unit also has an on/off switch, which should be in the off position.
3. When you have finished vacuuming simply unplug the cuff of the hose out of the inlet and hold the door of the inlet open for five (5) seconds until the suction subsides.

Note: This vacuum is not intended for use by young children or infirmed persons without supervision. Young children should be supervised to ensure that they do not play with the vacuum.

At the Vacuum Power Unit

1. Insert the hose cuff into the inlet adjacent to the vacuum power unit.
2. Turn the unit on using the ON/OFF switch. When finished, turn the switch to the OFF position again.

Note: To use the inlets inside the house, the switch must be in the OFF position.



MAINTENANCE & CARE OF YOUR SYSTEM

Your power unit is warranted against defective materials and workmanship but not against misuse. There is a service charge for repairing or replacing damaged or misused components of the system or for unnecessary service calls.

1. Do not suck up flammable and non-flammable liquids, chemicals, cement, lime and plaster powders.
2. Do not leave the central vacuum system on unattended.
3. Use only one inlet at a time to maintain maximum suction.
4. Hold the inlet door open for five (5) seconds after removing the hose. This will make sure that the unit has stopped and clear any residual dirt out of the pipe system.
5. To empty the dust bucket, undo both clips and lower the bucket. Remove the cone and empty the bucket. Replacement is the reverse of this procedure.
6. Each time you empty the bucket or if the suction is diminished you must clean or replace the filter. To remove the filter, remove the dust bucket to gain access to the filter. Unscrew the filter holder anticlockwise and pull the filter down. Replacement is the reverse of this procedure.

Sponge filters can be washed using cold water only. Allow it to dry thoroughly before reinstalling.

If Cartridge filters are used, you may attempt to remove excess dust by shaking and brushing. If this is unsuccessful and the filter is unserviceable, it should be replaced. Please note a spare filter is supplied with your new vacuum.

Additional filters are available through your Installation Company.

The filter must be reinstalled before using your vacuum. Using the vacuum without the filter could result in permanent damage to the motor and void any warranties.

7. Empty dust bucket periodically or when dust reaches 5cm from bottom of cone.
8. Do not store property on top of power unit, as this will restrict the cooling airflow, which may cause the motor to over heat. Do not use the system if a blockage occurs.
9. Read the Warranty Card.

WARRANTY

This Ducted Vacuum has been built to DAS specification from quality materials. It is warranted to be free of defects in materials, workmanship and mechanical performance for a period of one (1) year from the date of purchase for domestic installations and 500 hours operation for commercial installations.

This warranty is additional to any statutory requirements.

Warranty Conditions

- This warranty applies only to the DAS Ducted Vacuum unit. It does not apply to piping and fittings.
- All warranty claims must be accompanied by original proof of purchase.
- The vacuum must have been used in accordance with the User Guide and maintenance instructions.
- All costs associated with the transport of goods under warranty claim are the responsibility of the claimant.
- DAS' reserve the right to repair or replace goods at its own discretion.
- DAS' reserve the right to act as final arbiter in all warranty claims.

Their warranty does not apply if the defect occurs as a result of:

- Misuse, neglect or accidental damage.
- Scratches, dents or blemishes which occur after the purchase date.
- The unit being used for any other purpose other than that for which it was designed.